A SELECTION FROM OUR VAST RANGE OF





For spare parts and servicing, please contact your nearest dealer, or CLARKE International on:

020 8988 7400

or e-mail: parts@clarkeinternational.com or: service@clarkeinternational.com
HEMNALL STREET, EPPING, ESSEX CM16 4LG



SUBMERSIBLE TRANSFER PUMP

IVI

Model No: MSP12

Part No: 7260040



Thank you for purchasing this Clarke Mini Submersible Pump.

Please read this leaflet thoroughly before use to ensure you are fully aware of the limitations and methods of use and all safety precautions that must be taken into consideration. This will ensure the safety of yourself and others in the vicinity and also ensure that with proper use, the pump will provide you with many years of satisfactory service.

Guarantee

This CLARKE product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

Contents

- 1 pump c/w 4 metre supply cable with crocodile clips.
- 3 metres flexible hose.
- 2 x 15mm jubilee clips
- 15mm steel tube x 150mm length.

Please check the contents to ensure they are complete and that no damage has occurred in transit.

Should any damage be apparent, please contact your Clarke dealer immediately



When disposing of this product, do not dispose of with general waste. It must be disposed of according to the laws governing Waste Electrical and Electronic equipment, at a recognised disposal facility.

Limitations of Use

This pump is **ONLY** for use with the following:

- Clean water or water with small solids in suspension (dirty water).
- Diesel fuel
- Paraffin

DO NOT use this pump for pumping:

- Slurry
- Septic tanks
- Sandy water
- WARNING: DO NOT USE FOR PUMPING PETROL

Safety Precautions

- ALWAYS disconnect the pump from the power supply before performing any maintenance.
- ALWAYS check the power cable before use to ensure it is perfectly serviceable.
- **ALWAYS** ensure the filter is clean and perfectly serviceable before use.
- NEVER run the pump dry. Minimum water depth is 30mm.
- DO NOT exceed the duty cycle see Specifications.
- DO NOT use if any part appears to be damaged. Have it repaired by your Clarke dealer.
- DO NOT use the pump for any purpose other than that for which it is intended.
- DO NOT operate the pump continuously eg. in a fish pond or collection tank, water feature etc.
- DO NOT use or leave the pump in freezing conditions.
- DO NOT allow uncontrolled discharge of contaminated water etc. ALWAYS collect in a container and dispose of according to all H & S and local regulations.

Specifications

Flow Rate	. 16.5 litres/min
Min. Water Depth	. 30mm
Voltage	. 12V
Current	. 4.5A DC
Pressure	. 15psi / 1 bar
Height	. 145mm
Diameter	. 53.5mm
Weight	. 0.6kg
Duty cycle	. 15mins continuous in any 30 min period

We declare that this product complies with the following EEC directive - 98/37EC

signed:

Mr D. Kemp, Engineering Mgr Dated 30 Nov 2007

Method of Operation

- 1. Always check to ensure the pump is in perfect working order:
 - has no apparent damage
 - the filter is in place and is perfectly clean
 - the power cable is in perfect condition
- 2. Attach the flexible hose to the outlet, securing with the jubilee clip supplied.
- 3. If required, attach the stainless steel tube to the discharge end of the flexible hose, securing with the jubilee clip supplied.
- 4. Carefully lower the pump into the pit or sump etc, to be drained.

IMPORTANT; if the bottom of the pit or sump is muddy or sandy, position the pump on a brick or similar support. DO NOT allow it to rest in the mud or sand.

5. Connect the clamps to the 12Volt battery and the pump will operate.

IMPORTANT: ALWAYS connect the red - positive clamp to the red positive terminal of the battery FIRST, then connect the black clamp to the black - negative terminal, ensuring both clamps are perfectly secure.

When disconnecting - ALWAYS disconnect the black - negative clamp FIRST.

Always observe the pump discharging. Should performance deteriorate during use, it is probable that the filter is becoming blocked. In this case, disconnect the pump from the battery - (black terminal first), then carefully remove the pump from the pit or sump etc. **DO NOT yank the cable**.

Unscrew the base cap and remove the filter. Either clean thoroughly or replace as necessary, then check the impeller to ensure it is free to rotate and is not blocked.

When satisfied, replace pump in sump or pit and resume pumping.

When finished ALWAYS remove the filter and clean thoroughly, then allow it to dry.

Thoroughly clean the pump with clean water and ensure the impeller is completely free to rotate and is free of contaminants.

Reassemble the pump and store in a clean dry environment.

Parts and Service

The following parts are available from your Clarke dealer

 1. End Cap
 Part No:
 MSP1201

 2. Filter
 MSP1202

 3. Cable Clamp - Red
 MSP1203

 4. Cable Clamp - Black
 MSP1204

 5. Flexible Hose - 4M
 MSP1205

For Spare Parts and Service, please contact your nearest dealer, or CLARKE International, on one of the following numbers.

PARTS & SERVICE TEL: 020 8988 7400 PARTS & SERVICE FAX: 020 8558 3622 or e-mail as follows:

PARTS: Parts@clarkeinternational.com SERVICE: Service@clarkeinternational.com