

Charlton®



INFRARED QUARTZ WALL HEATER

MODEL NO: IQ2000

PART NO: 6939004

MOUNTING & OPERATION INSTRUCTIONS

UK
CA | CE



ORIGINAL INSTRUCTIONS

DL1123 - ISS 4

INTRODUCTION

Thank you for purchasing this CLARKE Infrared Wall Heater.

Before attempting to use this product, please read this manual thoroughly and follow the instructions carefully. In doing so you will ensure the safety of yourself and that of others around you, and you can look forward to your purchase giving you long and satisfactory service.

FUNCTION AND OPERATING PARAMETERS

This is infrared heater. It's intended use is for drying and the warming of commercial/industrial buildings where adequate ventilation is provided.

- It must be operated as prescribed in the operating manual.
- Is not intended to be used for domestic use or for the heating of habitable areas.
- Is not intended to be used to reach and maintain a certain level of human thermal comfort within an enclosed space in which the heater is situated.
- Is not intended to be used in enclosed areas with restricted ventilation.
- Is not for use in areas with high levels of fluctuating drafts.
- Is not intended for warming animals or live stock.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

SAFETY PRECAUTIONS

GENERAL

1. **ALWAYS** read and ensure you fully understand the following precautions and the hazards associated with this type of heater. **DO NOT** allow anyone who has not read these instructions to operate this heater. Please keep these instructions in a safe place for future reference.
2. **ALWAYS** check for damage before using the heater. **DO NOT** use the heater if dropped or there are visible signs of damage. Any damage should be properly repaired or the part replaced. If in doubt, **DO NOT** use the heater and consult your local Clarke dealer.
3. **NEVER** carry out any modifications to this product. If experiencing difficulty of any kind consult your local dealer.
4. Use the heater in accordance with any applicable fire regulations.

OPERATING ENVIRONMENT

1. **NEVER** use the heater where petrol, paint thinners or other highly flammable vapour or where high levels of airborne dust may be present.
2. **DO NOT** use this heater in the immediate surrounds of a bath, a shower or a swimming pool.
3. Disconnect the heater from the power supply when not in use.
4. **NEVER** place anything on top of the heater so as to impede free air flow.
5. **DO NOT** expose the heater or power cable to rain or wet conditions. Any water entering the heater will increase the risk of electric shock. If used outdoors, the heater should be protected from direct rainfall.
6. **NEVER** locate the heater near combustible materials such as curtains, furniture etc. Allow at least 1 metre distance.
7. Allow a distance of at least 1 metre from adjacent wall and avoid installing the heater close to power socket outlets.
8. **DO NOT** allow the heating element to become covered with dust which could become a fire hazard. If used in a dusty workplace it should be cleaned as described under Cleaning and Maintenance.
9. **NEVER** touch the heater element for at least 15 minutes after switching off.
10. **DO NOT** leave the heater unattended.
11. **DO NOT** use this heater with a programmable timer used to switch it on automatically.
12. **NEVER** attach any duct work in front of the heater.



PERSONAL SAFETY

1. When the heater is to be operated in the presence of other people the user is responsible for informing those present of the safety precautions and of the hazards involved.
2. This heat should only be used for commercial or industrial use. The heater should **NOT** be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
3. **CAUTION:** Some parts of this product can become very hot and cause burns. **ALWAYS** ensure that people and animals are kept well away from the heater when in operation.
4. This heater will be hot when in operation and should not be touched until it has fully cooled down after switching off.
5. **NEVER** leave the heater in use without adult supervision if children or animals are likely to be present.
6. **DO NOT** use this heater in small rooms when occupied by persons unable to leave the room on their own unless constant supervision is provided.

ELECTRICAL SAFETY

1. Make sure that the voltage on the rating label is the same voltage as the power supply. If in doubt consult a qualified electrician.
2. **NEVER** modify the plug in any way. **DO NOT** use adaptor plugs with earthed appliances. Correct plugs and outlets will reduce the risk of electric shock.
3. **DO NOT** abuse the electrical cable. Keep the cable away from sources of heat, sharp edges or moving parts. Damaged or tangled cables increase the risk of electric shock.
4. Regularly inspect the power cable for damage. **DO NOT** use if damaged & keep it away from the source of heat. If damaged, it must be replaced.

SAFETY SYMBOLS

	Hot surface, DO NOT touch.		DO NOT cover.
---	-----------------------------------	---	----------------------

The above symbols are found on the heater.

ELECTRICAL CONNECTIONS




WARNING! READ THESE ELECTRICAL SAFETY INSTRUCTIONS THOROUGHLY BEFORE CONNECTING THE PRODUCT TO THE MAINS SUPPLY.

Before switching the product on, make sure that the voltage of your electricity supply is the same as that indicated on the rating plate. This product is designed to operate on 230VAC 50Hz. Connecting it to any other power source may cause damage.


This product may be fitted with a non-rewireable plug. If it is necessary to change the fuse in the plug, the fuse cover must be refitted. If the fuse cover becomes lost or damaged, the plug must not be used until a suitable replacement is obtained.

If the plug has to be changed because it is not suitable for your socket, or due to damage, it should be cut off and a replacement fitted, following the wiring instructions shown below. The old plug must be disposed of safely, as insertion into a mains socket could cause an electrical hazard.

If the colours of the wires in the power cable of this product do not correspond with the markings on the terminals of your plug, proceed as follows.

- The wire which is coloured **Blue** must be connected to the terminal which is marked **N** or coloured **Black**.
- The wire which is coloured **Brown** must be connected to the terminal which is marked **L** or coloured **Red**.
- The wire which is coloured **Yellow and Green** must be connected to the terminal which is marked **E** or  or coloured **Green**.

Plug must be BS1363/A approved.



Ensure that the outer sheath of the cable is firmly held by the clamp

We strongly recommend that this machine is connected to the mains supply via a Residual Current Device (RCD)

If in any doubt, consult a qualified electrician. **DO NOT** attempt any repairs yourself.

PREPARATION

UNPACKING

Remove heater from the carton and check for any damage sustained in transit. Notify your Clarke dealer immediately of any defects.

MOUNTING THE HEATER



The heater is resistant to splashing but should be sheltered from direct rainfall, as should the power cable, plug and supply outlet socket. If used outdoors, an awning, overhanging roof or other shelter should be used to protect from rain.

The heater must be mounted on a suitable wall at a height not less than 1.8m above the floor.

The heater should be positioned with at least 1m clearance at the front between the heater and any obstruction including walls or other combustible surfaces. Always position the heater facing the centre of the space to be heated, not pointing directly at any nearby surfaces. Never place any objects on, or against the heater.


Any equipment or furniture should be a safe distance away, as they could be adversely affected by heat. Take care that the heat is not directed at curtains or other fabrics.

1. Drill four holes in the wall to accept the plastic wall-plugs supplied, at the distance apart as shown. Other wall plugs may be required, dependant upon the construction of the wall.
2. Screw the mounting bracket to the wall.
3. Fit the heater onto the wall bracket and secure in place with the screw knob.
4. Set the downwards angle of the heater by loosening the mounting bracket with a large x-head screwdriver and adjusting the angle before re-tightening.



OPERATION

1. Connect the mains cable to a suitable power socket.
2. Pull the string repeatedly to cycle through the following heat settings;
 - **O** = Off
 - **I** = Low
 - **II** = Medium
 - **III** = High



CLEANING AND MAINTENANCE



WARNING: BEFORE CARRYING OUT ANY MAINTENANCE, ENSURE THE HEATER IS SWITCHED OFF, DISCONNECTED FROM THE MAINS SUPPLY, AND HAS BEEN GIVEN ADEQUATE TIME TO COOL DOWN.

PERIODICALLY

1. If there is any build up of dirt, wipe thoroughly with a damp cloth, taking care that no moisture enters the heater.
2. Inspect the power cable for damage. Undue heat will cause the cable to stiffen and crack in which case it should be replaced.
3. Ensure heating elements are free of dust (use compressed air to clean if possible). (ALWAYS wear a dust mask if performing this task).
4. Refer to your Clarke dealer if the heater element needs replacing.

DAMAGE & REPAIRS

1. If necessary, have your heater repaired by a qualified person using identical replacement parts to maintain the safety of the heater.


FAULT FINDING

SYMPTOM	PROBLEM	SOLUTION
Heater does not operate, although plugged in and switched on.	Plug is loose/ bad connection.	Remove the plug & check the connection of the plug and socket.
	Fuse blown.	Replace if necessary and investigate the cause. If fuse blow repeatedly, consult your Clarke dealer.
	No power at socket outlet	Insert plug into an operational socket.
	Input voltage incorrect.	Ensure power supply matches the rating on the label.

TECHNICAL SPECIFICATION

Dimensions (L x W x H)	178 x 480 x 253 mm
Weight	1.9 kg
Electrical Supply	230 V, 50hz
Power Cable length	1.8 m
Protection Degree	IP24 (water splash resistant)
Operating Temperature	-20 to 30
Tilt Range	Level to -25 degrees
Heat Output	2kW

PARTS DIAGRAM



PARTS LIST

ID	DESCRIPTION	ID	DESCRIPTION
1	Front Housing	21	Nut
2	Front Housing Clip	22	Internal Wire Assembly
3	Heating Element	23	PVC Sticker
4	Self-tapping Screw	24	Cable Bush
5	Reflector Bracket	25	Drawing Bush
6	Reflector	26	Display Disc
7	Nut	27	Cable Clamp
8	Cable Clip	28	Plastic Plug
9	Self tapping Screw	29	Switch
10	Spring Washer	30	Self tapping Screw
11	Rear Housing	31	Self tapping Screw
12	Hinge Board	32	Screw Knob
13	U-seal Ring	33	Switch Bracket
14	Hinge Seal	34	Wall Bracket
15	Hinge	35	Star Washer
16	Screw	36	Power Cable
17	Control Box Bottom	37	Self-tapping Screw
18	Closed End Connector	38	Self-tapping Screw
19	Seal	39	Screw
20	Control Box Cover		

ENVIRONMENTAL RECYCLING POLICY



Through purchase of this product, the customer is taking on the obligation to deal with the WEEE in accordance with the WEEE regulations in relation to the treatment, recycling & recovery and environmentally sound disposal of the WEEE.

In effect, this means that this product must not be disposed of with general household waste. It must be disposed of according to the laws governing Waste Electrical and Electronic Equipment (WEEE) at a recognised disposal facility.

DECLARATION OF CONFORMITY



Hemnell Street, Epping, Essex, CM16 4LG

DECLARATION OF CONFORMITY

This is an important document and should be retained.

We hereby declare that this product(s) complies with the following statutory requirement(s):

Electromagnetic Compatibility Regulations 2016
Electrical Equipment (Safety) Regulations 2016.
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012.

The following standards have been applied to the product(s):

*EN 55014-1:2017, EN 55014-2:2015, EN IEC 61000-3-2:2019, EN 61000-3-3:2013 +A1:2019,
EN 60335-2-30:2009 +A11:2012, EN 60335-1:2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019
+A2:2019, EN 62233:2009.*

The technical documentation required to demonstrate that the product(s) meet(s) the requirement(s) of the aforementioned legislation has been compiled and is available for inspection by the relevant enforcement authorities.

The UKCA mark was first applied in: 2021

Product Description: Infrared heater(s)
Model number(s): IQ2000, IQ2000S
Serial / batch Number: N/A
Date of issue: 25/05/2021

Signed:

J.A. Clarke
Director



Fitzwilliam Hall, Fitzwilliam Place, Dublin 2

DECLARATION OF CONFORMITY

This is an important document and should be retained.

We hereby declare that this product(s) complies with the following directive(s):

2014/30/EU Electromagnetic Compatibility Directive.
2014/35/EU Low Voltage Equipment Directive.
2011/65/EU Restriction of Hazardous substances.

The following standards have been applied to the product(s):

*EN 55014-1:2017, EN 55014-2:2015, EN IEC 61000-3-2:2019, EN 61000-3-3:2013 +A1:2019,
EN 60335-2-30:2009 +A11:2012, EN 60335-1:2012 +A11:2014 +A13:2017 +A1:2019 +A14:2019
+A2:2019, EN 62233:2009.*

The technical documentation required to demonstrate that the product(s) meet(s) the requirement(s) of the aforementioned directive(s) has been compiled and is available for inspection by the relevant enforcement authorities.

The CE mark was first applied in: 2014

Product Description: Infrared heater(s)
Model number(s): IQ2000, IQ2000S
Serial / batch Number: N/A
Date of issue: 25/05/2021

Signed:

J.A. Clarke
Director

A SELECTION FROM THE VAST RANGE OF

Clarke®

QUALITY PRODUCTS



AIR COMPRESSORS
From DIY to industrial, Plus air tools, spray guns and accessories.

GENERATORS
Prime duty or emergency standby for business, home and leisure.

POWER WASHERS
Hot and cold, electric and engine driven - we have what you need

WELDERS
Mig, Arc, Tig and Spot. From DIY to auto/industrial.

METALWORKING
Drills, grinders and saws for DIY and professional use.

WOODWORKING
Saws, sanders, lathes, mortisers and dust extraction.

HYDRAULICS
Cranes, body repair kits, transmission jacks for all types of workshop use.

WATER PUMPS
Submersible, electric and engine driven for DIY, agriculture and industry.

POWERTOOLS
Angle grinders, cordless drill sets, saws and sanders.

STARTERS/CHARGERS
All sizes for car and commercial use.



PARTS & SERVICE: 0208 988 7400

Parts Enquiries
Parts@clarkeinternational.com

Servicing & Technical Enquiries
Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

Clarke INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG
www.clarkeinternational.com