

FLEXIBLE DRIVE SHAFT ATTACHMENT

Model CHT626
Part No 1801626

USER INSTRUCTIONS

(E

GC1009

INTRODUCTION

Thank you for purchasing this CLARKE Drive Shaft Attachment.

Before attempting to use this product, it is essential that you read this manual thoroughly and carefully follow all instructions given. In doing so you will ensure the safety of yourself and that of others around you, and you can also look forward to the product giving you long and satisfactory service.

GUARANTEE

This CLARKE product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase. This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for its intended purpose.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission. This guarantee does not effect your statutory rights.

ENVIRONMENTAL PROTECTION



Do not dispose of this product with general household waste. Any tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of appropriately.

TECHNICAL SPECIFICATIONS

Length	1250 mm
Hand grip length	180 mm
Chuck capacity	1.0 - 10.0 mm
Chuck type	3/8" - 24 UNF
Torque (maximum)	8 N/m
Maximum rated speed	6500 rpm
Weight	0.75 kg
Drive end type	Round 8 mm



SAFETY PRECAUTIONS

ALWAYS take care that your hands or clothing do not come into contact with the chuck of the drill which drives this attachment. Beware of wearing loose clothing & ensure cuffs are secured.

ALWAYS learn the applications, limitations and potential hazards relating to the tool you are using. Read and become familiar with all operating instructions.

ALWAYS wear safety goggles manufactured to the latest European Safety Standards when drilling. Everyday eyeglasses do not have impact resistant lenses and are not safety glasses.

ALWAYS check for damage before use to ensure that the tool will operate properly. If in doubt, do not use. Consult your local dealer. Any damage should be properly repaired or the part replaced.

ALWAYS check for alignment of moving parts and any condition that may affect operation.

ALWAYS keep work area clean. Cluttered areas invite accidents.

ALWAYS ensure that adequate lighting is available and that you will not be working in your own shadow.

ALWAYS concentrate on the job in hand, no matter how trivial it may seem. Be aware that accidents are caused by carelessness.

USER INSTRUCTIONS

The CHT626 Drill Attachment is ideal for drilling, polishing, grinding or sanding in a confined area in conjuntion with most power drills.

- 1. Install the attachment into the chuck of your power drill. Install a drill bit into the chuck using the chuck key provided and tighten securely.
- 2. Plug in and switch on, with the drill set to a reasonably slow speed until confident of the drilling capability.
- 3. When drilling, use a steady pressure. Do not force the drill, but allow the drill bit to do the work. It may be necessary to adjust the speed to suit the size of drill bit and the material.
- 4. As a general guide, the larger the hole, the slower the speed required, also the harder the material being cut, the slower the speed.

CAUTION

- Never use with a drill in 'hammer' mode.
- This product must only be used within its maximum speed rating of 6500rpm.





PARTS & SERVICE: 0208 988 7400

E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

CIAPLE INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG
www.clarkeinternational.com