
Instant Garage 6,1 x 3,7 x 2,4 m Assembly Instructions



















RECOMMENDED TOOLS

DESCRIPTION	MODEL #
Instant Garage 6,1 x 3,7 x 2,4 m - Grey	CIG 1220
	3503502



Clarke International
Hemnall Street
Epping
Essex CM16 4LG
ENGLAND
www.clarkeinternational.com

PARTS & SERVICE: 0208 988 7400 E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com

SALES: UK 01992 565333 or EXPORT: 00 44 (0)1992 565335

12/19/12 1 05 62653 A3

ATTENTION:

This shelter product is manufactured with quality materials. It is designed to fit the garage custom fabric cover included. Please anchor the shed carefully following the instructions in this manual. Proper anchoring, keeping cover tight and free of snow and debris is the responsibility of the consumer. Please read and understand the installation detail, warnings and cautions prior to beginning installation.

DANGER:

Choose the location of your garage carefully. **DANGER:** *Keep away from electrical wires.* Check for overhead utility lines, tree branches or other structures. Check for underground pipes or wires before you dig. DO NOT install near roof lines or other structures that could shed snow, ice or excessive run off onto your shelter. DO NOT hang objects from the roof or support cables.





WARNING:

Risk of fire. DO NOT smoke or use open flame devices (including grills, fire pits, deep fryers, smokers or lanterns) in or around the garage. DO NOT store flammable liquids (gasoline, kerosene, propane, etc.) in or around your shelter. Do not expose top or sides of the shelter to open fire or other flame source.





CAUTION:

Use CAUTION when erecting the frame.

PROPER ANCHORING AND INSTALLATION OF FRAME:

PROPER ANCHORING OF THE FRAME IS THE RESPONSIBILITY OF THE CONSUMER.

Clarke® International is not responsible for damage to the unit or the contents from acts of nature. Any garage that is not anchored securely has the potential to fly away causing damage. Periodically check the anchors to ensure stability of the shelter. Clarke® International cannot be responsible for any shelter that blows away. NOTE: Your shelter's cover can be quickly removed and stored prior to severe weather conditions. If strong winds or severe weather is forecast in your area, we recommend removal of cover.


2


CARE AND CLEANING:


A tight cover ensures longer life and performance. Always maintain a tight cover. Loose fabric can accelerate deterioration of cover fabric. Immediately remove any accumulated snow or ice from the roof structure with a broom, mop or other soft-sided instrument. Use extreme caution when removing snow from cover- always remove from outside the structure. DO NOT use hard-edged tools or instruments like rakes or shovels to remove snow. This could result in punctures to the cover. DO NOT use bleach or harsh abrasive products to clean the fabric cover. Cover is easily cleaned with mild soap and water.





05 62653 A3













E.




















WARNING!


Shelter MUST be securely anchored. Serious injury could result.














H.




















12

I.

