

Incorrect or out of phase engine timing can result in damage to the valves. The Tool Connection cannot be held responsible for any damage caused by using these tools in anyway.

Safety Precautions – Please read

- Disconnect the battery earth leads (check radio code is available)
- Remove spark or glow plugs to make the engine turn easier
- Do not use cleaning fluids on belts, sprockets or rollers
- Always make a note of the route of the auxiliary drive belt before removal
- Turn the engine in the normal direction (clockwise unless stated otherwise)
- Do not turn the camshaft, crankshaft or diesel injection pump once the timing chain has been removed (unless specifically stated)
- Do not use the timing chain to lock the engine when slackening or tightening crankshaft pulley bolts
- Do not turn the crankshaft or camshaft when the timing belt/chain has been removed
- Mark the direction of the chain before removing
- It is always recommended to turn the engine slowly, by hand and to re-check the camshaft and crankshaft timing positions.
- Crankshafts and Camshafts may only be turned with the chain drive mechanism fully installed.
- Do not turn crankshaft via camshaft or other gears
- Check the diesel injection pump timing after replacing the chain
- Observe all tightening torques
- Always refer to the vehicle manufacturer's service manual or a suitable proprietary instruction book
- Incorrect or out of phase engine timing can result in damage to the valves
- It is always recommended to turn the engine slowly, by hand, and to re-check the camshaft and crankshaft timing positions



www.lasertools.co.uk



Distributed by The Tool Connection Ltd
Kineton Road, Southam, Warwickshire CV47 9DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee


If this product fails through faulty materials or workmanship, contact our service department direct on: **+44 (0) 1926 818186**. Normal wear and tear are excluded as are consumable items and abuse.

www.lasertools.co.uk

LASER[®]


Part No. 4346

Engine Timing Tools VAG 2.0 TDi PD DOHC



www.lasertools.co.uk

Plan Layout



| Ref | Code | Oem Code | Description |
|-----|------|------------------|--|
| A | C157 | T10050 310-085 | Crankshaft Setting Tool Bored engines |
| B | C304 | T10100 | Crankshaft Setting Tool Non Bored engines |
| C | C216 | 3359 T20102 | Injection Pump Locking Pins (2) |
| D | C283 | T10060/A | Auxiliary drive belt tensioner locking pin |
| E | C282 | T10115 | Tensioner Pulley Locking Pin |

Applications

The application list for this product has been compiled cross referencing the OEM Tool Code with the Component Code.

In most cases the tools are specific to this type of engine and are necessary for Cam belt or chain maintenance.

If the engine has been identified as an interference engine valve to piston damage will occur if the engine is run with a broken Cam belt.

A compression check of all cylinders should be performed before removing the cylinder head.

Always consult a suitable work shop manual before attempting to change the Cam belt or Chain.

The use of these engine timing tools is purely down to the user's discretion and Tool Connection cannot be held responsible for any damage caused what so ever.

ALWAYS USE A REPUTABLE WORKSHOP MANUAL

| Manufacturer | Model | Engine Code | Year |
|--------------|------------------|-----------------------------|---------|
| Audi | A4 | BLB BNA BRE BRF BVG | 2004-07 |
| | A6 | BLB BNA BRE BRF BVG | 2004-07 |
| Skoda | Octavia II | AZV BKD | 2004-07 |
| Volkswagen | Golf Golf Plus | AZV BKD | 2003-07 |
| | Jetta | AZV BKD | 2003-07 |
| | Passat | BKP | 2009 |
| | Touran | AZV BKD | 2003-07 |