



EAR DEFENDERS

MODEL NO: SED1

PART NO: 8133818

USER INSTRUCTIONS



ORIGINAL INSTRUCTIONS

DL0722 REV 1

INTRODUCTION

Thank you for purchasing this CLARKE product. Before attempting to use this product, please read these instructions carefully. In doing so you will ensure your safety and you can look forward to your purchase giving you long and satisfactory service.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for its intended purpose. Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

SPECIFICATIONS

Product weight	249 g
Product dimensions	200 x 700 x 200 mm (L x D x W)

ATTENUATION VALUES

SNR	29dB	H:	32dB	M:	27dB	L:	20dB			
Frequency (Hz)			63	125	250	500	1000	2000	4000	8000
Mean Attenuation dB			n/a	17.3	21	28.9	37.7	33.1	37.8	34.9
Standard Deviation dB			n/a	3.1	3.3	4.6	3.7	3.3	3.6	3.6
APV dB			n/a	14.2	17.7	24.3	34	29.8	34.2	31.3

MATERIALS DECLARATION

No parts of the ear defenders are made of materials that are known to cause skin irritation. However, materials that come into contact with the skin can cause allergic reactions to certain susceptible individuals.

USING EAR DEFENDERS

Always ensure that the ear defenders are correctly fitted, adjusted and maintained.

Extend the headband and place the cups over the ears with the headband passing over the head. Settle into position while adjusting the height of the ear cups until comfortable with the headband providing support.

The ear cushions should be a snug fit against the head.

Adjust the pressure on the head by bending of the headband and ensure an effective noise seal.

Wear the ear defenders throughout all periods of exposure to noise.

CLEANING, MAINTENANCE AND STORAGE

Clean only with warm soapy water as this product may be adversely affected by certain chemical substances such as organic solvents or alcohol.

Occasionally disinfect any part of the ear defenders in contact with the wearer if there are multiple users. Use a product not harmful to the wearer.

Ear defenders should be regularly inspected for condition as the protection afforded may eventually become impaired. The ear cushions may deteriorate with use and should be examined at frequent intervals for cracking.

In order to avoid the possibility of deterioration in the materials quality and performance, we suggest replacing the ear defenders after 2-3 years of regular use.

When not in use, it is recommended to store this product in a clean, dry polythene bag.

DECLARATION OF CONFORMITY





Hemnall Street, Epping, Essex CM16 4LG

DECLARATION OF CONFORMITY

This is an important document and should be retained.

Safety Ear Defenders 29dB

× 07/07/2022

Serial / batch Number:

Model number(s): Product Description:

Date of Issue:

NB2754

21, Rue Albert Einstein ALIENOR CERTIFICATION

86100 ZA du Sanital

France Chatellerault

We hereby declare that this product(s) complies with the following statuary requirement(s): Personal Protective Equipment Regulations 2016/425

The following standards have been applied to the product(s):

EN 352-1:2002

The technical documentation required to demonstrate that the product(s) meet(s) the requirement(s) of the transcribed and is available for inspection by the relevant enforcement authorities. The technical documentation

Where applicable, the PPE is subject to the conformity assessment procedure conformity to type based on internal production control plus supervised product checks at random intervals (Module C2) under surveillance of the notified body

The UKCA mark was first applied ip: 202

J.A. Clarke Director

Signed:

SEDI UKCA Clarke DOC 070722

Page 1 of 1

SED1 CE CLarke DOC 070722

Page 1 of 1

Notified Body: Date of Issue: Model number(s): Product Description:

Serial / batch Number:

SED1

Safety Ear Defenders 29dB

N N

07/07/2022 NB2754

21, Rue Albert Einstein ALIENOR CERTIFICATION

ZA du Sanital

86100 Chatellerault

We hereby declare that this product(s) complies with the following directive(s): Regulation (EU), Personal Protective Equipment

2016/425

The following standards have been applied to the product(s):

EN 352-1:2002

The technical documentation required to demonstrate that the product(s) meet(s) the requirement(s) or aforementioned directive(s) has been compiled and is available for inspection by the relevant enforcement authorities

Where applicable, the PPE is subject to the conformity assessment procedure conformity to type based on internal production control plus supervised product checks at random intervals (Module C2) under surveillance of the notified body (see details above) The CE mark was first applied in: 2019

J.A. Clarke Director

Signed:

DECLARATION OF CONFORMITY Fitzwilliam Hall, Fitzwilliam Place, Dublin 2

This is an important document and should be retained

Parts & Service 0208 988 7400 E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com Clarke International, Hemnall Street, Epping, Essex CM16 4LG