

DRAPER®

D20
MULTI-TOOL BATTERY SYSTEM

GB

20V

LED WORKLIGHT

55876



CE

These instructions accompanying the product are the original instructions. This document is part of the product, keep it for the life of the product passing it on to any subsequent holder of the product. Read all these instructions before assembling, operating or maintaining this product.

This manual has been compiled by Draper Tools describing the purpose for which the product has been designed, and contains all the necessary information to ensure its correct and safe use. By following all the general safety instructions contained in this manual, it will ensure both product and operator safety, together with longer life of the product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product.

Whilst every effort has been made to ensure the accuracy of information contained in this manual, the Draper Tools policy of continuous improvement determines the right to make modifications without prior warning.

1. TITLE PAGE

1.1 INTRODUCTION:

USER MANUAL FOR: 20V LED WORKLIGHT

Stock No:55876

Part No:D20ILF3W

1.2 REVISIONS:

Date first published November 2018.

As our user manuals are continually updated, users should make sure that they use the very latest version.

Downloads are available from: <http://drapertools.com/manuals>

Draper Tools Limited

Hursley Road

Chandler's Ford

Eastleigh

Hampshire

SO53 1YF

UK

Website: drapertools.com

Product Helpline: +44 (0) 23 8049 4344

General Fax: +44 (0) 23 8026 0784

1.3 UNDERSTANDING THIS MANUALS SAFETY CONTENT:

WARNING! – Information that draws attention to the risk of injury or death.

CAUTION! – Information that draws attention to the risk of damage to the product or surroundings.

1.4 COPYRIGHT © NOTICE:

Copyright © Draper Tools Limited.

Permission is granted to reproduce this publication for personal and educational use only. Commercial copying, redistribution, hiring or lending is prohibited.

No part of this publication may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases this copyright notice must remain intact.

2. CONTENTS

1	TITLE PAGE	
1.1	INTRODUCTION	2
1.2	REVISION HISTORY	2
1.3	UNDERSTANDING THIS MANUAL	2
1.4	COPYRIGHT NOTICE	2
2	CONTENTS	
2.1	CONTENTS.....	3
3	GUARANTEE	
3.1	GUARANTEE	4
4.	INTRODUCTION	
4.1	SCOPE	5
4.2	SPECIFICATION	5
4.3	HANDLING & STORAGE	5
5.	HEALTH AND SAFETY INFORMATION	
5.1	GENERAL SAFETY INSTRUCTIONS FOR POWER TOOL USE	6-7
5.2	ADDITIONAL SAFETY INSTRUCTIONS FOR TORCHES	7
5.3	RESIDUAL RISK	7
6.	TECHNICAL DESCRIPTION	
6.1	IDENTIFICATION	8
7.	UNPACKING AND CHECKING	
7.1	PACKAGING	9
7.2	D20 MULTI-TOOL INTERCHANGEABLE BATTERY SYSTEM	9
8.	PREPARING THE TORCH	
8.1	UNPACKING YOUR TORCH	10
8.2	INSTALLING A BATTERY	10
8.3	REMOVING A BATTERY.....	10
9.	BASIC TORCH OPERATIONS	
9.1	ON/OFF SWITCH.....	11
9.2	7 PRESET ANGLE POSITIONS	11
9.3	270° SWIVELLING HEAD	11
9.4	HANGING HOOK.....	11
10.	MAINTENANCE	
10.1	MAINTENANCE	12
10.2	TRANSPORT & STORAGE	12
11.	OPTIONAL ACCESSORIES	
11.1	OPTIONAL ACCESSORIES.....	13
12.	DISPOSAL	
12.1	DISPOSAL.....	14
	DECLARATION OF CONFORMITY	ENCLOSED

3. WARRANTY

3.1 WARRANTY

Draper tools have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship.

Should the tool develop a fault, please return the complete tool to your nearest distributor or contact:

Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF. England.

Telephone Sales Desk: (023) 8049 4333 or:

Product Helpline (023) 8049 4344.

A proof of purchase must be provided.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This warranty period covering labour is 12 months from the date of purchase except where tools are hired out when the warranty period is 90 days from the date of purchase. The warranty is extended to 24 months for parts only. This warranty does not apply to any consumable parts, any type of battery or normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any personnel other than the authorised Draper warranty repair agent.

Note: If the tool is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.

This warranty applies in lieu of any other warranty expressed or implied and variations of its terms are not authorised.

Your Draper warranty is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the warranty period.

Please note that this warranty is an additional benefit and does not affect your statutory rights.

Draper Tools Limited.

4. INTRODUCTION

4.1 SCOPE

3 watt Chip On Board (COB) LED rechargeable inspection lamp, to be used as an inspection lamp or as a torch. A hang hook. Worklight swivels and angles.

This product is intended for domestic and infrequent light trade use only. Any application other than that it was intended for, is considered misuse.

4.2 SPECIFICATION

Stock no.	55876
Part no.	D20ILF3W
Rated voltage	20V
Spotlight	3W COB LED
Lamp luminosity	100 lumens.
Swivel torch head	0-270°
Head stops	0, 45°, 90°, 135°, 180°, 225°, 270°
Angle torch head	0-180°
Positive stops	0, 30°, 60°, 90°, 120°, 150°, 180°
Dimensions (L x W x H)	2295 x 65 x 90mm
Weight (machine only).....	0.4kg

4.3 HANDLING & STORAGE

- Care must be taken when handling this product.
 - Dropping this power tool could have an effect on its accuracy and could also result in personal injury. This product is not a toy and must be respected.
- Environmental conditions can have a detrimental effect on this product if neglected.
 - Exposure to damp air can gradually corrode components.
 - If the product is unprotected from dust and debris, components will become clogged.
 - If not cleaned and maintained correctly or regularly, the machine will not perform at its best.

5. HEALTH AND SAFETY INFORMATION

5.1 GENERAL SAFETY INSTRUCTIONS FOR POWER TOOL USE

When using any type of power tool there are steps that should be taken to make sure that you, as the user, remain safe.

Common sense and a respect for the tool will help reduce the risk of injury.

Read the instruction manual fully. Do not attempt any operation until you have read and understood this manual.

Most important you must know how to safely start and stop this machine, especially in an emergency.

Keep the work area tidy and clean. Attempting to clear clutter from around the machine during use will reduce your concentration. Mess on the floor creates a trip hazard. Any liquid spill on the floor could result in you slipping.

Find a suitable location. If the machine is bench mounted, the location should provide good natural light or artificial lighting as a replacement. Avoid damp and dust locations as it will have a negative effect on the machine's performance. If the machine is portable do not expose the tool to rain. In all cases do not operate power tools near any flammable materials.

Keep bystanders away. Children, onlookers and passers by must be restricted from entering the work area for their own protection. The barrier must extend a suitable distance from the tool user.

Unplug and house all power tools that are not in use. A power tool should never be left unattended while connected to the power supply. They must be housed in a suitable location, away locked up and from children. This includes battery chargers.

Do not overload or misuse the tool. All tools are designed for a purpose and are limited to what they are capable of doing. Do not attempt to use a power tool (or adapt it in any way) for an application it is not designed for. Select a tool appropriate for the size of the job. Overloading a tool will result in tool failure and user injury. This covers the use of accessories.

Dress properly. Loose clothing, long hair and jewellery are all dangerous because they can become entangled in moving machinery. This can also result in parts of body being pulled into the machine. Clothing should be close fitted, with any long hair tied back and jewellery and neck ties removed. Footwear must be fully enclosed and have a non-slip sole.

Wear personal protective equipment (PPE). Dust, noise, vibration and swarf can all be dangerous if not suitably protected against. If the work involving the power tool creates dust or fumes wear a dust mask. Vibration to the hand, caused by operating some tools for longer periods must be protected against. Wear vibration reducing gloves and allow long breaks between uses. Protect against dust and swarf by wearing approved safety goggles or a face shield. These are some of the more common hazards and preventions, however, always find out what hazards are associated with the machine/work process and wear the most suitable protective equipment available.

Do not breathe contaminated air. If the work creates dust or fumes connect the machine (if possible) to an extraction system either locally or remotely. Working outdoors can also help if possible.

Move the machine as instructed. If the machine is hand held, do not carry it by the power supply cable. If the product is heavy, employ a second or third person to help move it safely or use a mechanical device. Always refer to the instructions for the correct method.

Do not overreach. Extending your body too far can result in a loss of balance and you falling. This could be from a height or onto a machine and will result in injury.

Maintain your tools correctly. A well maintained tool will do the job safely. Replace any damaged or missing parts immediately with original parts from the manufacturer. As applicable, keep blades sharp, moving parts clean, oiled or greased, handles clean, and emergency devices working.

5. HEALTH AND SAFETY INFORMATION

Wait for the machine to stop. Unless the machine is fitted with a safety brake, some parts may continue to move due to momentum. Wait for all parts to stop, then unplug it from the power supply before making any adjustments, carrying out maintenance operations or just finishing using the tool.

Remove and check setting tools. Some machinery requires the use of additional tools or keys to set, load or adjust the power tool. Before starting the power tool always check to make certain they have been removed and are safely away from the machine.

Prevent unintentional starting. Before plugging any machine in to the power supply, make sure the switch is in the OFF position. If the machine is portable, do not hold the machine near the switch and take care when putting the machine down, that nothing can operate the switch.

Carefully select an extension lead. Some machines are not suitable for use with extension leads. If the tool is designed for use outdoors, use an extension lead also suitable for that environment. When using an extended lead, select one capable of handling the current (amps) drawn by the machine in use. Fully extend the lead regardless of the distance between the power supply and the tool. Excess current (amps) and a coiled extension lead will both cause the cable to heat up and can result in fire.

Concentrate and stay alert. Distractions are likely to cause an accident. Never operate a power tool if you are under the influence of drugs (prescription or otherwise), including alcohol or if you are feeling tired. Being disorientated will result in an accident.

Have this tool repaired by a qualified person. This tool is designed to conform to the relevant international and local standards and as such should be maintained and repaired by someone qualified, using only original parts supplied by the manufacturer. This will ensure the tool remains safe to use.

5.2 ADDITIONAL SAFETY INSTRUCTIONS FOR TORCHES

Special safety instructions for torches

When the torch is switched on, the following must be observed:

- Do not look directly into the lens.
- Do not shine into a person's eyes or an animal's eyes
- Do not point the beam at cars, motorcycles, aircraft, ships or any other vehicle or machinery that is operated by a person. bright light can be blinding and you could cause a serious accident.
- In case of damage and improper use of the battery, vapours may be emitted. Ventilate the area and seek medical help in case of complaints. The vapours can irritate the respiratory system.

5.3 RESIDUAL RISK

Important note: Although the safety instructions and operating manuals for our tools contain extensive instructions for safe working with power tools, every power tool involves a certain residual risk which can not be completely excluded by safety mechanisms. Power tools must therefore always be operated with caution!

6. TECHNICAL DESCRIPTION

6.1 IDENTIFICATION



- ① COB LED.
- ② 270° Swivelling head.
- ③ 7 Preset angle positions.
- ④ Hanging hook.
- ⑤ On/Off switch.

7. UNPACKING AND CHECKING

7.1 PACKAGING

Carefully remove the product from the packaging and examine it for any sign of damage that may have happened during shipping. Lay the contents out and check them against the parts shown below. If any part is damaged or missing, please contact the Draper Help Line (the telephone number appears on the Title page) and do not attempt to use the product.

The packaging material should be retained at least during the warranty period, in case the machine needs to be returned for repair.

Warning!

- Some of the packaging materials used may be harmful to children. Do not leave any of these materials in the reach of children.
- If any of the packaging is to be thrown away, make sure they are disposed of correctly, according to local regulations.

7.2 D20 MULTI-TOOL INTERCHANGEABLE BATTERY SYSTEM

The D20 range of tools are a range of tools suitable for enthusiasts and tradespersons alike, featuring a wide array of machines all running from the same range of batteries. Many different capacity batteries are available making sure you can balance tool weight with longevity and find a battery that meets your needs. To find out the latest range of accessories including batteries and chargers please consult the Draper website for more information or to find your local Draper stockist.



8. PREPARING THE TORCH

8.1 UNPACKING YOUR TORCH

- Carefully unpack and inspect your torch. Fully familiarise yourself with all its features and functions.
- Ensure that all parts of the torch are present and in good condition. If any parts are missing or damaged, have such parts replaced before attempting to use the torch.

8.2 INSTALLING A BATTERY

Note: For instructions regarding charging batteries and other battery information, please read the supplied instructions with the batteries.

- Fit a charged battery by sliding it onto the base of the worklight until it clicks and locks into position.

Note: Make sure the battery and worklight are lined up correctly. If the battery does not slide onto the base of the worklight easily, don't force it. Instead, slide the battery out of the worklight and check the top of the battery and the battery slot of the worklight are clean and undamaged, and that the contacts are not bent.

8.3 REMOVING A BATTERY

- Remove the battery from the worklight by pressing the battery release button on the battery; then slide the battery off the base of the worklight.

Warning: DO NOT try to remove the battery without pressing the battery release button, otherwise the tool or battery may be damaged.



FIG.3

9. BASIC TORCH OPERATIONS

9.1 ON/OFF SWITCH

Switch the Torch on or off by pressing the On/Off Switch.



FIG.3

9.2 7 PRESET ANGLE POSITIONS

Adjust the torch head assembly angle at the Angle Joint. It adjusts from 0 - 180° with 6 click stop positions.



FIG.4

9.3 270° SWIVELLING HEAD

Adjust the Spotlight direction by turning the Spotlight at the Swivel Joint (2). It adjusts from 0 - 270° with 6 click stop positions.

Note: Be careful not to damage the worklight when adjusting the angle and swivel positions.




FIG.4

9.4 HANGING HOOK

The worklight features a built in hanging hook. Push upwards to release from the tool body.



FIG.4

10. MAINTENANCE

10.1 MAINTENANCE

Cleaning and correct maintenance of the tool is important for both safety and for the service life of the tool.

Note: Switch off the tool and disconnect it from the power supply (remove the battery/ unplug the power cord) before cleaning and maintenance - risk of electrical shock and accidental starting.

- Wipe the tool with a cloth moistened with water and a few drops of soap or detergent. Brush clean hard to reach areas with a brush.

Note: Do not use cleaning agents that contain solvents or abrasive or corrosive additives - risk of damaging tool surfaces.

- Clear the tool vents and the accessory mount after each use of with brush and cloth.
- Stubborn contamination in areas hard to access can be removed with compressed air.
- Always check after each use that any accessories are free from damage.
- Remove the accessory from the tool's drive after each use and clean the drive.

Warning:

- Brake fluid, petrol, mineral oil and petroleum products must not come into contact with the plastic parts of the power tool. This can damage or deform the plastic.
- Always wear safety goggles that seal against the face and also protect from the side when using compressed air to blow clean the power tool. When performing very dusty work, a dust mask should also be worn.

10.2 TRANSPORT & STORAGE

- Clean the tool as instructed and allow it to dry.
- If the tool shall remain unused for any length of time, it should be stored in the original packaging.
- Store the tool in a dry place, well ventilated and out of the reach of children.
- Always shut off the tool before transport.
- Always carry the tool using the purpose-designed handle.
- Ensure that the tool is not at risk of tipping over or exposed to vibration and shocks during transport, especially if the tool will be transported by car or other vehicle.

11. OPTIONAL ACCESSORIES

11.1 OPTIONAL ACCESSORIES

A full range of accessories are available from Draper Tools.

Please visit our website for details: www.drapertools.com

12. DISPOSAL

12.1 DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area.

In all circumstances:

- Do not dispose of power tools with domestic waste.
- Do not incinerate.
- Do not dispose of WEEE* as unsorted municipal waste.



* *Waste Electrical & Electronic Equipment.*

NOTES

CONTACTS

Draper Tools Limited, Hursley Road,
Chandler's Ford, Eastleigh, Hampshire. SO53 1YF. U.K.

Helpline: (023) 8049 4344

Sales Desk: (023) 8049 4333

Internet: drapertools.com

E-mail: sales@drapertools.com

General Enquiries: (023) 8026 6355

Service/Warranty Repair Agent:

For aftersales servicing or warranty repairs, please contact the Draper Tools Helpline for details of an agent in your local area.

YOUR DRAPER STOCKIST

TAKC1118

©Published by Draper Tools Limited.

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical photocopying, recording or otherwise without prior permission in writing from Draper Tools Ltd.