


WORKBENCH

MODEL NO: CWB1700P

PART NO: 4501510

OPERATION & MAINTENANCE INSTRUCTIONS

LS1119



















Thank you for purchasing this CLARKE WorkBench.

Before attempting to use this product, please read this manual thoroughly and follow the instructions carefully. In doing so you will ensure the safety of yourself and that of others around you, and you can look forward to your purchase giving you long and satisfactory service.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

SPECIFICATIONS

Model Number	CWB1700P	
Part Number	4501510	
Weight	72 kg	
Dimensions (L x W x H)	1700 x 600 x 850 mm	

SAFETY NOTICE

PLEASE NOTE THAT DUE TO THE WEIGHT OF THIS PRODUCT, IT IS RECOMMENDED THAT TWO PEOPLE LIFT IT IN TO POSITION.



Parts & Service: 020 8988 7400 / E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com




















The following items should be supplied in the carton. If any parts are missing or damaged, please see your CLARKE dealer where you purchased the workbench.

Left Left	Drawer Slide (Type A) x 4	Drawer Bottom x 5
Middle Leg	Drawer Slide (Type B) x 3	Shelf x 1
Right Leg	Drawer Slide (Type C) x 3	Door x 1
Upper Panel	Foot x 6	Door Lock x 1
Lower Panel	Drawer Front x 5	Rear Angle Bracket x 1
Divider	Drawer Side x 10	Front Angle Bracket x 1
Rear Panel	Drawer Back x 5	Bag of Nuts /Bolts and Washers

DRAWER SLIDE IDENTIFICATION



1. There are three types of drawer slide supplied 4 x Type 'A', 3 x Type 'B' and 3 x Type 'C'



Parts & Service: 020 8988 7400 / E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com





















ASSEMBLE THE DRAWERS



1. Fit the drawer sides to the drawer bottom as shown and use two M4x8 bolts, washers and nuts in the central 2 holes to secure in place.

NOTE: The nuts and washers must be fitted to the inside of the drawer.



2. Connect the drawer back to the assembly as shown using 5 M4x8 Bolts, washers and nuts.



























- 3. Connect the drawer front to the assembly as shown using 5 M4x8 Bolts, washers and nuts.
- 4. Repeat steps 1-3 for the remaining four drawers, giving you a total of five drawers



5. Locate the 4 upper drawer slides Type `A' there should be two left and two right.


























- 6. Fit the drawer slides (Type `A') to two of the drawers as follows
 - Extend the drawer slide by hand
 - Line up the drawer slide with the top of the drawer as shown.
 - Secure each slide using three M4 screws, washers and nuts,

NOTE: The nuts and washers must be fitted to the inside of the drawer.

Place all drawers to one side for now, you will fit them later.



Parts & Service: 020 8988 7400 / E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com























ASSEMBLE THE MAIN FRAME




1. Locate and identify the three legs as shown.



2. Connect the upper panel to the left leg as shown using 3 M5x8 Bolts, washers and nuts.

































4. Fit the divider between the upper and lower panels using 4 M5x8 Bolts, washers and nuts.

8 -

























5. Connect the middle leg to the upper and lower panels as shown using 6 M5x8 Bolts, washers and nuts.



Carefully stand the workbench up and fit the back panel as shown using 12 M5x8 Bolts, washers and nuts.




























7. Remove the 3 M5x8 Bolts, washers and nuts that connect the middle leg to the upper panel, this is nessecery to enable you to fit the door.



8. Fit the door as shown and then replace the 3 M5x8 Bolts, washers and nuts that you removed in the previous step.

























- 9. Place the shelf into position.
- 10. Tighten up all the nuts and bolts.
- 11. Fit the adjustable feet to the bottom of the legs including the right leg which will be fitted later.

























FITTING THE TOP AND RIGHT LEG



1. Lay the top upside down on the frame with the front towards you.



2. Lay the two completed drawers (with slides fitted on page 6) into position and secure using 8 wood screws supplied.





























- 3. With assistance, flip the top over and into postion as shown
- 4. Secure to the frame with 6 wood screws.



5. Place the right leg into postion and secure with 3 wood screws.


























- 6. Fit the support brackets as shown using wood screws and M5x8 bolts, washers and nuts
 - The larger bracket is fitted to the rear of the bench



























FITTING DOOR LOCK






IMPORTANT: Ensure the key remains in the lock until lock is fully fitted.

- Remove the locking lever securing screw and lock washer from the lock assembly, remove the lever, spring washer and washer noting which way round they are fitted for reassembly.
 - Take care to ensure the barrel does not fall out of the lock body.
- 2. Unscrew and remove the large securing nut, insert the lock into the hole in the door, refit the large securing nut and tighten with spanner,
 - DO NOT overtighten.
- 3. Turn the key fully anticlockwise (locked position), fit the lever as shown
- 4. Secure the lever with the spring washer, washer and securing screw.
- 5. Check that the lock works properly i.e. anticlockwise = locked and clockwise = unlocked.


























1. Insert the tongues into the slots on the legs and allow the drawer slide to swing down and rest on the leg, no fixings are requires



- 2. Starting with the bottom drawer, pull out the drawer slides as far as possible.
- 3. Lay the drawer into position as shown and secure each slide to the drawer using countersunk screws, washers and nuts,

























- 4. Make sure that you tighen all bolts and screws
- 5. Before using the bench for the first tme, we recommend the application of a waterproof wood preservative to the bench top to prevent staining from oil spills etc.
- 6. The bench is now ready to use.





























PARTS & SERVICE: 0208 988 7400 E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

CIAPLE INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG www.clarkeinternational.com











